



Mesh – Teil | Part 1/6

Mesh ist eine innovative Dining- und Gourmetkollektion mit vielen variabel einsetz- und kombinierbaren Einzelteilen, z.B. für Tapas und Buffets. Ein zartes Gitterrelief macht die klaren, geometrischen Formen der Kollektion besonders lebhaft und modern. Die modernen Farbtöne Aqua, Cream und Mountain betonen perfekt die außergewöhnliche Struktur der Mesh Kollektion.



Durch die hohe Brenntemperatur von 1400°C schmilzt die spezielle Farbglasur in das Porzellan ein und lässt so auf jedem Teil einzigartige Farbverläufe entstehen. Mesh Colors steht für Modernität und lässt sich wunderbar kombinieren.

Mesh is an innovative dining and gourmet collection with many variably usable and combinable individual pieces, e.g. for tapas and buffets. What makes the well-defined geometric forms of the Mesh collection really special is the delicate, bamboo like Mesh relief. The modern color glazes Aqua, Cream and Mountain perfectly accentuate the beautiful texture of the Mesh collection.

Thanks to high firing at 1400°C, the special colored glaze melts into the porcelain and creates unique shades on each piece. Mesh colors reflects modernity and inspires new elegance.

Mesh - Teil | Part 2/6

Bestellnr. / Item no.
Artikel / Article



11770 - 10855

Teller flach rund 15 cm
Plate flat round 6 inch



11770 - 10349

Teller tief rund 19 cm
Plate deep round 7 1/2 inch



11770 - 10857

Teller flach rund 17 cm
Plate flat round 6 2/3 inch



11770 - 10351

Teller tief rund 21 cm
Plate deep round 8 1/4 inch




11770 - 10859

Teller flach rund 19 cm
Plate flat round 7 1/2 inch



11770 - 10355

Teller tief rund 25 cm
Plate deep round 9 7/8 inch



11770 - 10861

Teller flach rund 21 cm
Plate flat round 8 1/4 inch



11770 - 10158

Fahnenteller tief 28 cm
Rim plate deep 11 inch




11770 - 10864

Teller flach rund 24 cm
Plate flat round 9 1/2 inch




11770 - 10867

Teller flach rund 27 cm
Plate flat round 10 5/8 inch



11770 - 10870

Teller flach rund 30 cm
Plate flat round 11 3/4 inch





11770 - 10873

Teller flach rund 33 cm
Plate flat round 13 inch



Mesh - Teil | Part 3/6

Bestellnr. / Item no.
Artikel / Article



11770 - 16169

Teller flach quadratisch
Plate flat square
9x9 cm | 3 1/2x3 1/2 inch



11770 - 15299

1,30 l | 44 oz
Schale 18 cm
Bowl 7 1/8 inch
Höhe 9 cm | Hight 3 1/2 inch



11770 - 16174

Teller flach quadratisch
Plate flat square
14x14 cm | 5 1/2x5 1/2 inch



11770 - 15206

0,04 l | 1 3/8 oz
Universalschälchen 6 cm
Multipurpose bowl 2 1/3 inch



11770 - 16177

Teller flach quadratisch
Plate flat square
17x17 cm | 6 2/3x6 2/3 inch



11770 - 15454

0,55 l | 18 2/3 oz
Schale 14 cm
Bowl 5 1/2 inch



11770 - 16182

Teller flach quadratisch
Plate flat square
22x22 cm | 8 2/3x8 2/3 inch




11770 - 13324

2,30 l | 78 oz
Schüssel 24 cm
Bowl 9 1/2 inch



11770 - 16187

Teller flach quadratisch
27x27 cm
Plate flat square
10 5/8x10 5/8 inch



11770 - 15751

0,30 l | 10 oz
Schüssel oval 16x12 cm
Bowl oval 6 1/4x4 3/4 inch




11770 - 16191

Teller flach quadratisch
31x31 cm
Plate flat square
12 1/4x12 1/4 inch



11770 - 15752

0,68 l | 23 oz
Schüssel oval 20x15 cm
Bowl oval 7 7/8x5 7/8 inch



11770 - 16510

Teller tief quadratisch
Deep square plate
20x20 cm | 7 7/8x7 7/8 inch



11770 - 15296

1,20 l | 40 1/2 oz
Schüssel oval 25x18 cm
Bowl oval 9 7/8x7 1/8 inch




11770 - 10422

0,30 l | 10 1/8 oz
Suppen-Obertasse
Soup cup



11770 - 15290

Schale rund flach 12 cm
Bowl round flat 4 3/4 inch




11770 - 10421

Untertasse 18 cm
Saucer 7 inch





11770 - 15291

Schale rund tief 14 cm
Bowl round deep 5 1/2 inch




Mesh - Teil | Part 4/6



Bestellnr. / Item no.
Artikel / Article

11770 - 15289

Schale rechteckig
10x7 cm
Bowl rectangular
4x2 3/4 inch



11770 - 12718

Platte flach oval
18x12 cm
Platter flat oval
7x4 3/4 inch



11770 - 15288

Schale quadratisch
10x10 cm
Bowl square
4x4 inch



11770 - 12725

Platte flach oval
25x17 cm
Platter flat oval
9 7/8x6 2/3 inch



11770 - 15287

Schale rechteckig
20x10 cm
Bowl rectangular
7 7/8x4 inch



11770 - 12730

Platte flach oval
30x21 cm
Platter flat oval
11 3/4x8 1/4 inch




11770 - 12380

Teller/Platte flach rechteckig
(ohne Relief) 24x15 cm
Plate flat rectangular
(without relief) 9 1/2x6 inch



11770 - 12734

Platte flach oval
34x24 cm
Platter flat oval
13 1/2x9 1/2 inch




11770 - 12379

Teller/Platte flach rechteckig
(ohne Relief) 26x24 cm
Plate flat rectangular
(without relief)
10 1/4x9 1/2 inch




11770 - 12738

Platte flach oval
38x26 cm
Platter flat oval
15x10 1/4 inch




11770 - 12381

Teller/Platte flach rechteckig
(ohne Relief) 41x15 cm
Plate flat rectangular
(without relief) 16 1/8x6 inch



11770 - 12742

Platte flach oval
42x29 cm
Platter flat oval
16 1/2x11 3/8 inch




11770 - 12382

Platte flach rechteckig
18x13 cm
Platter flat rectangular
7x5 1/2 inch



11770 - 12383

Platte flach rechteckig
26x13 cm
Platter flat rectangular
10 1/4x5 1/2 inch



11770 - 12384

Platte flach rechteckig
34x13 cm
Platter flat rectangular
13 1/2x5 1/2 inch



Mesh - Teil | Part 5/6

Bestellnr. / Item no. Artikel / Article	800001 Weiß	405161 Colours Mountain	405152 Colours Aqua	405153 Colours Cream	800001 Weiß	405161 Colours Mountain	405152 Colours Aqua	405153 Colours Cream	
11770 - 14717 0,08 l 2 7/8 oz Obertasse Cup					11770 - 14345 Zuckerdosens-Deckel 10 cm Sugar bowl lid 4 inch				
11770 - 34607 0,09 l 3 oz Obertasse nieder Cup low		-	-	-	11770 - 14344 0,22 l 7 3/4 oz Zuckerdose Unterteil Sugar bowl base				
11770 - 14716 Untertasse 12 cm Saucer 4 3/4 inch					11770 - 14440 0,15 l 5 1/4 oz Gießer Creamer				
11770 - 14742 0,18 l 6 1/3 oz Obertasse Cup					11770 - 34002 Kaffeekannen-Deckel Lid for coffee pot		-	-	-
11770 - 14642 0,22 l 7 3/4 oz Obertasse Cup					11770 - 34001 0,30 l 10 1/2 oz Kaffeekannen-Unterteil Base for coffee pot		-	-	-
11770 - 14772 0,29 l 10 oz Obertasse Cup					11770 - 34212 Teekannen-Deckel Lid for teapot		-	-	-
11770 - 15505 0,35 l 12 1/3 oz Becher mit Henkel Mug with handle					11770 - 34211 0,40 l 14 oz Teekannen-Unterteil Base for teapot		-	-	-
11770 - 14741 Untertasse 16 cm Saucer 6 1/4 inch									

